



* Connect the **Normally Open** contacts of the Pulse Switch.

To the contacts of the pulse relay in the keypad

* Connect the **Normally Closed** contacts of the Delay Switch.

