New Feature – Door Controller Mode on Voyager

To allow our Voyager product range to act as a door controller for electrically activated locking mechanisms we have created a command to change the Normally Open (NO) relay contacts to Normally Closed (NC) which will be included in all of our Voyager products.

To put the GSM device into this mode simply text the following command to the device.

Send this text

| Door Mode On |

Receive this text

| Door Mode On |

To turn off this mode of operation use this command.

Send this text

| Door Mode Off |

Receive this text

| Door Mode Off |

The relay will latch and remain latched until the device receives a call or a text command to open the door.

When the device is power cycled this new mode is retained in the memory of the device and as soon as the device is powered up again the relay will switch back into this mode of operation immediately.