

# Voyager Mobile Entry Intercom(VME-I) Comelit Intercom with Keypad

## Wiring Diagram

Voyager Mobile Entry - Intercom and Access Control Unit.

2T-Technology

### Signal Strength.

1. On Steady: Strong Signal
2. Flashing: Acceptable Signal.
3. Off: No Signal.

### Register Status.

1. Off or On Constantly = NOT Registered
2. Flashing every second = Registered.

### Connection Key

GSM Unit	2	3	4	S1	S2	SX	OUT +	OUT -
Intercom	2	3	4 -	P1	P2	PX	+	4 -

